


Room W127

High Tech Classroom

by Dennis Mack, Audio Visual Technician



- 1** Power up: Turn on the Main Power Switch.
- 2** Turn on the Display Power.
- 3** Turn on the VCR, DVD or Computer
- 4** Select the mode for VCR, DVD, Computer or Laptop by pressing the appropriate button.
- 5** Adjust the Volume.
- 6** Connect your laptop computer here.
- 7** Power down:
 - a. Turn off peripheral equipment
 - b. Press the display power switch to turn off the projector.
 - c. Turn off the main power switch.

Laptop Audio and Video Connections



Laptop Internet Connection